

MODO REPETIDOR TOTOLINK PARA N150RH, N150RT, N151RT, N300RT, N301RT, N300RH

PASO 1

Ingresa al router N300RH que aparece en su listado de redes inalámbricas, una vez conectado abra su navegador de internet y coloque lo siguiente 192.168.1.1 le da enter y le pedirá un usuario y una contraseña en los casos es clave de usuario=admin / contraseña=admin Inicie sesión en la interfaz de configuración web del enrutador.

PASO 2


Haga clic en ADVANCE SETUP PARTE SUPERIOR DERECHA ->

The screenshot shows the web interface of a Totolink N300RH router. The browser address bar shows 192.168.1.1/wizardset.htm. The page has a dark header with the Totolink logo and the tagline 'The Smartest Network Device'. Below the header, it says 'Model No. N300RH (Firmware V2.8.3)' and has buttons for 'Advanced Setup' and 'Help'. The main content area is titled 'Easy Setup' and includes a sub-header 'The easy setup will guide you to configure AP for first time:'. There are four sections: 'Connect Status' with a status bar showing 'Getting IP from DHCP server... Disconnected'; 'Internet Setting' with a 'WAN Type' dropdown set to 'DHCP Client'; 'Wireless Setting' with 'SSID on/off' set to 'Enable', 'SSID' set to 'TOTOLINK N300RH', and 'Encryption' set to 'None'; and 'IPTV Settings' with 'IPTV On/Off' set to 'Disable'. At the bottom of the settings are 'Apply' and 'Reset' buttons. The footer contains the copyright notice 'Copyright©2015 TOTOLINK Ltd., All Rights Reserved'.

MODO REPETIDOR TOTOLINK PARA N150RH, N150RT, N151RT, N300RT, N301RT, N300RH

PASO 3

Click en OPERATION MODE y escoger como modo REPEATER (RANGE EXTENDER), darle el botón Apply/Next



MODO REPETIDOR TOTOLINK PARA N150RH, N150RT, N151RT, N300RT, N301RT, N300RH

PASO 4

Haga clic en el botón **"Site Survey"** para escanear la red inalámbrica y, a continuación, elija la red inalámbrica que desea repetir

Model No. N300RH (Firmware V2.9.3)

Easy Setup | Reset | Help

Wireless Repeater

This page allows you setup the wireless security. Turn on WEP or WPA by using Encryption Keys could prevent any unauthorized access to your wireless network.

Wireless Repeater On/Off:

SSID:

Encryption:

Authentication Mode: ☐ Enterprise (RADIUS) ☒ Personal (Pre-Shared Key)

WPA2 Cipher Suite: ☐ TKIP ☒ AES

Pre-Shared Key Format:

Pre-Shared Key:

SSID	BSSID	Channel	Type	Encrypt	Signal	Select
CLIENTES	10:28:53:6c:c1:52	11 (B+G+N)	AP	WPA-PSK/WPA2-PSK	100	☐
INFINITUM57CB	e4:a1:e5:02:d9:90	11 (B+G+N)	AP	WPA-PSK/WPA2-PSK	90	☐
TOTOLINK 2.4G	14:28:53:6c:c1:52	11 (B+G+N)	AP	WPA-PSK/WPA2-PSK	84	☐
INFINITUM17F2	14:c6:13:7c:e5:66	9 (B+G+N)	AP	WPA-PSK/WPA2-PSK	76	☐
INFINITUM8093	14:c6:13:81:c1:14	11 (B+G+N)	AP	WPA-PSK/WPA2-PSK	62	☐
INFINITUM854B	18:4a:6f:67:3c:94	1 (B+G+N)	AP	WPA-PSK/WPA2-PSK	60	☐
Victorynk Pasaje San Juan	4c:81:20:3d:fc:69	1 (B+G+N)	AP	WPA2-PSK	52	☐
clsc060-1	50:57:a8:67:26:0e	1 (B+G+N)	AP	no	46	☐
2.4	4c:81:20:39:a8:11	1 (B+G+N)	AP	WPA2-PSK	44	☐
ALMACENSJ	18:4a:6f:68:66:d8	11 (B+G+N)	AP	WPA-PSK/WPA2-PSK	44	☐

Copyright©2015 TOTOLINK Ltd., All Rights Reserved

MODO REPETIDOR TOTOLINK PARA N150RH, N150RT, N151RT, N300RT, N301RT, N300RH

PASO 4

Introduzca la contraseña de la red que señalo (la contraseña es la misma que viene en su modem de internet) y haga clic en **"FINISHED"** para terminar la configuración del repetidor. El repetidor se reiniciara y quedara listo.

Model No. N300RH (Firmware V2.9.3)

Easy Setup Reboot Help

Wireless Repeater

This page allows you setup the wireless security. Turn on WEP or WPA by using Encryption Keys could prevent any unauthorized access to your wireless network.

Wireless Repeater On/Off: Enabled

SSID: CLIENTES

Encryption: WPA2

Authentication Mode: Enterprise (RADIUS) Personal (Pre-Shared Key)

WPA2 Cipher Suite: TKIP AES

Pre-Shared Key Format: Passphrase

Pre-Shared Key: *****

Back Finished Site Survey

SSID	BSSID	Channel	Type	Encrypt	Signal	Select
CLIENTES	86:28:53:8c:c1:52	11 (B-G+N)	AP	WPA-PSK/WPA2-PSK	100	+
INFINITUM57CE	64:a1:e0:02:95:90	11 (B-G+N)	AP	WPA-PSK/WPA2-PSK	90	+
TOTOLINK 2.4G	84:28:53:8c:c1:52	11 (B-G+N)	AP	WPA-PSK/WPA2-PSK	84	+
INFINITUM17F2	84:c6:13:7c:a5:88	9 (B-G+N)	AP	WPA-PSK/WPA2-PSK	78	+
INFINITUM8033	84:c6:13:81:c0:14	11 (B-G+N)	AP	WPA-PSK/WPA2-PSK	62	+
INFINITUM854B	15:4a:67:67:3c:94	1 (B-G+N)	AP	WPA-PSK/WPA2-PSK	60	+
Victorynê Parque San Juan	4c:31:20:2a:1c:69	1 (B-G+N)	AP	WPA2-PSK	52	+
disco05-1	50:57:a8:67:26:d6	1 (B-G+N)	AP	no	46	+
2.4	4c:31:20:30:a8:11	1 (B-G+N)	AP	WPA2-PSK	44	+
ALVACENSJ	15:4a:67:68:86:d8	11 (B-G+N)	AP	WPA-PSK/WPA2-PSK	44	+

Copyright©2010 TOTOLINK Ltd., All Rights Reserved

PASO 5

MODO REPETIDOR TOTOLINK PARA N150RH, N150RT, N151RT, N300RT, N301RT, N300RH

Para saber si quedo listo tu modem entra a tus redes inalámbricas y la red TOTOLINK ya no deberá de estar disponible .
